

Procedure for upgrading Valkyrie chassis with Thor-400G-7S-1P module(s) from Release 79.1 (or lower) to Release 79.2 (or higher)

Upgrading a Valkyrie chassis with a Thor-400G-7S-1P module from Release 79.1 (or lower) to Release 79.2 (or higher) involves two important steps:

1. First upgrade the chassis
2. Then upgrade the module(s) in the chassis

STEP ONE

UPGRADE CHASSIS


- a. Open the ChassisUpgrader
- b. In the **Defined Test Chassis** section: Select one (or more) chassis to upgrade
- c. Check **Upgrade =>** **Allow Upgrade to Same Version**
- d. Press **Synchronize Chassis Information**



<input checked="" type="checkbox"/> Select All Upgrades <input type="checkbox"/> Deselect All Upgrades <input type="checkbox"/> Expand All <input type="checkbox"/> Collapse All				
Upgrade Selection Overview				
This panel show the available upgrades for your chassis and testmodules. Note that the panel will only show the st				
Select an item to view a detailed overview of the available upgrade actions for that item.				
Name	Model	FW Version	Sel.	Available Upgrades
<input checked="" type="checkbox"/> Chassis 'New chassis' (192.168.1.202:22606)	C4-12 (b) [FC20]	S.442.5 D.38	<input checked="" type="checkbox"/>	<input type="checkbox"/> Chassis Firmware
<input type="checkbox"/> L23 Test Module 6	M1QSFDDQSF56	294	<input type="checkbox"/>	<input type="checkbox"/> Module Firmware


- e. Check the **Sel.** box for the chassis **only** (as illustrated above); make sure that module(s) are **not** selected
- f. Press **Start Upgrade** and wait for the chassis to be upgraded. Please observe that the chassis will reboot and automatically start up again – **do not power cycle the chassis in this part of the upgrade process**

STEP TWO

UPGRADE MODULE(S)

- a. When the chassis is reconnected press  Synchronize Chassis Information again
- b. Check the **Sel.** box(es) for the module(s) in the chassis as illustrated below:

<input checked="" type="checkbox"/> Select All Upgrades <input type="checkbox"/> Deselect All Upgrades <input type="button" value="Expand All"/> <input type="button" value="Collapse All"/>				
Upgrade Selection Overview This panel show the available upgrades for your chassis and testmodules. Note that the panel will only show the status for t Select an item to view a detailed overview of the available upgrade actions for that item.				
Name	Model	FW Version	Sel.	Available Upgrades
<input type="checkbox"/> Chassis 'New chassis' (192.168.1.202:22606)	C4-12 (b) [FC20]	S.442.11 D.38	<input type="checkbox"/>	 Chassis Firmware Upgrade
<input checked="" type="checkbox"/> L23 Test Module 6	M1QSFDDQSP56	294	<input checked="" type="checkbox"/>	 Module Firmware Upgrade

- c. Press  Start Upgrade and follow the instructions on the screen
- d. After a power cycle, your chassis and modules will have been upgraded to the new release